

山东大学

SHANDONG UNIVERSITY



Ranorex

实验报告

课程名称：软件质量保证与测试技术

姓名：武敬信

学号：202000800525

专业班级：21软件工程1班

授课教师：康钦马

2024 年 4 月 3 日

-
- 1 实验目的
 - 2 实验环境
 - 3 实验步骤
 - 3.1 Ranorex 部署
 - 3.2 录制 Ranorex 测试脚本
 - 3.3 利用代码进行功能测试

1 实验目的

通过实验，要初步掌握 Ranorex 的使用、以及代码编辑来实现自动化功能测试的方法。

2 实验环境

虚拟机：Windows 10 x64

软件：Ranorex 8


CPU：AMD Ryzen 7 5800H

内存：8GB

3 实验步骤

3.1 Ranorex 部署

文件下载到个人电脑之后需要解压安装。使用试用版的 Ranorex。安装完成后的界面如下：



3.2 录制 Ranorex 测试脚本

以 [计算器](#) 为例，进行 Ranorex 测试脚本录制。

新建一个名为 Test1 的项目。项目建成之后，会展示项目界面，并且自动生成一个默认的recording：

Recording1


Success

Computer/Endpoint	Execution time
R9000K	2024/5/26 20:20:43
Operating system	Screen dimensions
Windows 10 64bit	2560x1600
OS Language	
zh-CN	
Total errors	Total warnings
0	0


Filter: <input checked="" type="checkbox"/> Info <input checked="" type="checkbox"/> Success			
Time	Level	Category	Message
00:00.596	Info	Application	Run application 'C:\Windows\System32\calc.exe' with arguments '' in normal mode.
00:00.656	Info	Delay	Waiting for 1s.
00:01.666	Info	Mouse	Mouse Left Click item 'WindowsApp计算器.ClearButton' at 86;33.
00:04.037	Info	Delay	Waiting for 200ms.
00:04.239	Info	Mouse	Mouse Left Click item 'WindowsApp计算器.NumberPad.Text1' at 2;20.
00:05.484	Info	Mouse	Mouse Left Click item 'WindowsApp计算器.StandardOperators.SomeText1' at 13;0.
00:06.446	Info	Mouse	Mouse Left Click item 'WindowsApp计算器.NumberPad.Num1Button' at 83;30.
00:07.562	Info	Mouse	Mouse Left Click item 'WindowsApp计算器.StandardOperators.SomeText' at 5;11.
00:08.511	Info	Validation	Validating AttributeEqual (Text='显示为 2') on item 'WindowsApp计算器.CalculatorResults'.
00:08.618	Success	Validation	Attribute 'Text' of element for item 'Test1Repository.WindowsApp计算器.CalculatorResults' does match the specified value.
00:08.729	Info	Mouse	Mouse Left Click item 'WindowsApp计算器.Close' at 17;26.

3.3 利用代码进行功能测试


在录制的时候，Ranorex 会生成一份 C# 代码，展示了 Ranorex 内部录制的代码。



用户可以自己进行修改代码实现对其他功能的测试，例如下图所示：



比如在这里，添加了逻辑：`1+11=12`，并启动测试。



测试出来的结果是符合预期的，代表功能正常。接下来，进行其他等价类的功能测试，这就需要测试乘法、除法等等。

测试代码（自定义用户脚本）如下：

```

using System;
using System.Collections.Generic;
using System.Text;

```

```

using System.Threading;
using WinForms = System.Windows.Forms;

using Ranorex;
using Ranorex.Core;
using Ranorex.Core.Repository;
using Ranorex.Core.Testing;

namespace Test1
{
    public partial class Recording1
    {
        /// <summary>
        /// This method gets called right after the recording has been started.
        /// It can be used to execute recording specific initialization code.
        /// </summary>
        private void Init()
        {
            // Your recording specific initialization code goes here.

            //打开
            Report.Log(ReportLevel.Info, "Application", "Run application
'C:\\Windows\\System32\\calc.exe' with arguments '' in normal mode.", new
RecordItemIndex(0));
            Host.Local.RunApplication("C:\\Windows\\System32\\calc.exe", "",
"C:\\Windows\\System32", false);
            Delay.Milliseconds(0);

            Report.Log(ReportLevel.Info, "Delay", "Waiting for 1s.", new
RecordItemIndex(1));
            Delay.Duration(1000, false);

            // 清零
            Report.Log(ReportLevel.Info, "Mouse", "Mouse Left Click item 'WindowsApp计算
器.ClearButton' at 86;33.", repo.WindowsApp计算器.ClearButtonInfo, new RecordItemIndex(2));
            repo.WindowsApp计算器.ClearButton.Click("86;33");
            Delay.Milliseconds(200);

            //加法 1+11=12
            Report.Log(ReportLevel.Info, "Mouse", "Mouse Left Click item 'WindowsApp计算
器.NumberPad.Text1' at 2;20.", repo.WindowsApp计算器.NumberPad.Text1Info, new
RecordItemIndex(4));
            repo.WindowsApp计算器.NumberPad.Text1.Click("2;20");
            Delay.Milliseconds(200);

            Report.Log(ReportLevel.Info, "Mouse", "Mouse Left Click item 'WindowsApp计算
器.StandardOperators.SomeText1' at 13;0.", repo.WindowsApp计算
器.StandardOperators.SomeText1Info, new RecordItemIndex(5));
            repo.WindowsApp计算器.StandardOperators.SomeText1.Click("13;0");
            Delay.Milliseconds(200);

            Report.Log(ReportLevel.Info, "Mouse", "Mouse Left Click item 'WindowsApp计算
器.NumberPad.Num1Button' at 83;30.", repo.WindowsApp计算器.NumberPad.Num1ButtonInfo, new
RecordItemIndex(6));

```

```

        Delay.Milliseconds(200);

        Report.Log(ReportLevel.Info, "Mouse", "Mouse Left Click item 'WindowsApp计算器.NumberPad.Num1Button' at 83;30.", repo.WindowsApp计算器.NumberPad.Num1ButtonInfo, new RecordItemIndex(6));
        repo.WindowsApp计算器.NumberPad.Num1Button.Click("83;30");
        Delay.Milliseconds(200);

        Report.Log(ReportLevel.Info, "Mouse", "Mouse Left Click item 'WindowsApp计算器.StandardOperators.SomeText' at 5;11.", repo.WindowsApp计算器.StandardOperators.SomeTextInfo, new RecordItemIndex(7));
        repo.WindowsApp计算器.StandardOperators.SomeText.Click("5;11");
        Delay.Milliseconds(200);

        Report.Log(ReportLevel.Info, "Validation", "Validating AttributeEqual (Text='显示为 12') on item 'WindowsApp计算器.CalculatorResults'.", repo.WindowsApp计算器.CalculatorResultsInfo, new RecordItemIndex(8));
        Validate.AttributeEqual(repo.WindowsApp计算器.CalculatorResultsInfo, "Text", "显示为 12");
        Delay.Milliseconds(100);

        //乘法 2*7=14

        Report.Log(ReportLevel.Info, "Mouse", "Mouse Left Click item 'WindowsApp计算器.NumberPad.Num2Button' at 124;10.", repo.WindowsApp计算器.NumberPad.Num2ButtonInfo, new RecordItemIndex(11));
        repo.WindowsApp计算器.NumberPad.Num2Button.Click("124;10");
        Delay.Milliseconds(200);

        Report.Log(ReportLevel.Info, "Mouse", "Mouse Left Click item 'WindowsApp计算器.StandardOperators.MultiplyButton' at Center.", repo.WindowsApp计算器.StandardOperators.MultiplyButtonInfo, new RecordItemIndex(10));
        repo.WindowsApp计算器.StandardOperators.MultiplyButton.Click();
        Delay.Milliseconds(200);

        Report.Log(ReportLevel.Info, "Mouse", "Mouse Left Click item 'WindowsApp计算器.NumberPad.Num7Button' at 0;16.", repo.WindowsApp计算器.NumberPad.Num7ButtonInfo, new RecordItemIndex(10));
        repo.WindowsApp计算器.NumberPad.Num7Button.Click("0;16");
        Delay.Milliseconds(200);

        Report.Log(ReportLevel.Info, "Mouse", "Mouse Left Click item 'WindowsApp计算器.StandardOperators.SomeText' at 5;11.", repo.WindowsApp计算器.StandardOperators.SomeTextInfo, new RecordItemIndex(7));
        repo.WindowsApp计算器.StandardOperators.SomeText.Click("5;11");
        Delay.Milliseconds(200);

        Report.Log(ReportLevel.Info, "Validation", "Validating AttributeEqual (Text='显示为 14') on item 'WindowsApp计算器.CalculatorResults'.", repo.WindowsApp计算器.CalculatorResultsInfo, new RecordItemIndex(8));
        Validate.AttributeEqual(repo.WindowsApp计算器.CalculatorResultsInfo, "Text", "显示为 14");
        Delay.Milliseconds(100);

```



```

        Report.Log(ReportLevel.Info, "Mouse", "Mouse Left Click item 'WindowsApp计算器.NumberPad.Num2Button' at 124;10.", repo.WindowsApp计算器.NumberPad.Num2ButtonInfo, new RecordItemIndex(11));
        repo.WindowsApp计算器.NumberPad.Num2Button.Click("124;10");
        Delay.Milliseconds(200);

        Report.Log(ReportLevel.Info, "Mouse", "Mouse Left Click item 'WindowsApp计算器.StandardOperators.DivideButton' at 19;29.", repo.WindowsApp计算器.StandardOperators.DivideButtonInfo, new RecordItemIndex(11));
        repo.WindowsApp计算器.StandardOperators.DivideButton.Click("19;29");
        Delay.Milliseconds(200);

        Report.Log(ReportLevel.Info, "Mouse", "Mouse Left Click item 'WindowsApp计算器.NumberPad.Num1Button' at 83;30.", repo.WindowsApp计算器.NumberPad.Num1ButtonInfo, new RecordItemIndex(6));
        repo.WindowsApp计算器.NumberPad.Num1Button.Click("83;30");
        Delay.Milliseconds(200);

        Report.Log(ReportLevel.Info, "Mouse", "Mouse Left Click item 'WindowsApp计算器.StandardOperators.SomeText' at 5;11.", repo.WindowsApp计算器.StandardOperators.SomeTextInfo, new RecordItemIndex(7));
        repo.WindowsApp计算器.StandardOperators.SomeText.Click("5;11");
        Delay.Milliseconds(200);

        Report.Log(ReportLevel.Info, "Validation", "Validating AttributeEqual (Text='显示为 1') on item 'WindowsApp计算器.CalculatorResults'.", repo.WindowsApp计算器.CalculatorResultsInfo, new RecordItemIndex(8));
        Validate.AttributeEqual(repo.WindowsApp计算器.CalculatorResultsInfo, "Text", "显示为 1");
        Delay.Milliseconds(100);

        //减法 7-2=5

        Report.Log(ReportLevel.Info, "Mouse", "Mouse Left Click item 'WindowsApp计算器.NumberPad.Num7Button' at 0;16.", repo.WindowsApp计算器.NumberPad.Num7ButtonInfo, new RecordItemIndex(10));
        repo.WindowsApp计算器.NumberPad.Num7Button.Click("0;16");
        Delay.Milliseconds(200);

        Report.Log(ReportLevel.Info, "Mouse", "Mouse Left Click item 'WindowsApp计算器.StandardOperators.MinusButton' at 119;2.", repo.WindowsApp计算器.StandardOperators.MinusButtonInfo, new RecordItemIndex(12));
        repo.WindowsApp计算器.StandardOperators.MinusButton.Click("119;2");
        Delay.Milliseconds(200);

        Report.Log(ReportLevel.Info, "Mouse", "Mouse Left Click item 'WindowsApp计算器.NumberPad.Num2Button' at 124;10.", repo.WindowsApp计算器.NumberPad.Num2ButtonInfo, new RecordItemIndex(11));
        repo.WindowsApp计算器.NumberPad.Num2Button.Click("124;10");
        Delay.Milliseconds(200);

        Report.Log(ReportLevel.Info, "Mouse", "Mouse Left Click item 'WindowsApp计算器.StandardOperators.SomeText' at 5;11.", repo.WindowsApp计算器

```

```

repo.WindowsApp计算器.StandardOperators.SomeText.Click("5;11");
Delay.Milliseconds(200);

Report.Log(ReportLevel.Info, "Validation", "Validating AttributeEqual (Text='显示为 5') on item 'WindowsApp计算器.CalculatorResults'.", repo.WindowsApp计算器.CalculatorResultsInfo, new RecordItemIndex(8));
Validate.AttributeEqual(repo.WindowsApp计算器.CalculatorResultsInfo, "Text", "显示为 5");
Delay.Milliseconds(100);

//关闭
Report.Log(ReportLevel.Info, "Mouse", "Mouse Left Click item 'WindowsApp计算器.Close' at 17;26.", repo.WindowsApp计算器.CloseInfo, new RecordItemIndex(9));
repo.WindowsApp计算器.Close.Click("17;26");
Delay.Milliseconds(200);
}

}
}

```


因为此处故意设置了错误，故其是能够发现功能异常的。当 `2/1=1` 时，ranorex会发现错误：


Recording1

Failed

Computer/Endpoint R9000K	Execution time 2024/5/26 22:58:15
Operating system Windows 10 64bit	Screen dimensions 2560x3200
OS Language zh-CN	
Total errors 1	Total warnings 0

Filter: ☒ Info ☒ Error ☒ Success ☒ Failure

Time	Level	Category	Message
00:00.616	Info	Application	Run application 'C:\Windows\System32\calc.exe' with arguments '' in normal mode.
00:00.680	Info	Delay	Waiting for 1s.
00:01.686	Info	Mouse	Mouse Left Click item 'WindowsApp计算器.ClearButton' at 86;33.
00:04.384	Info	Mouse	Mouse Left Click item 'WindowsApp计算器.NumberPad.Text1' at 2;20.
00:06.231	Info	Mouse	Mouse Left Click item 'WindowsApp计算器.StandardOperators.SomeText1' at 13;0.
00:07.368	Info	Mouse	Mouse Left Click item 'WindowsApp计算器.NumberPad.Num1Button' at 83;30.
00:08.811	Info	Mouse	Mouse Left Click item 'WindowsApp计算器.NumberPad.Num1Button' at 83;30.
00:10.442	Info	Mouse	Mouse Left Click item 'WindowsApp计算器.StandardOperators.SomeText' at 5;11.
00:11.532	Info	Validation	Validating AttributeEqual (Text='显示为 12') on item 'WindowsApp计算器.CalculatorResults'.
00:11.638	Success	Validation	Attribute 'Text' of element for item 'Test1Repository.WindowsApp计算器.CalculatorResults' does match the specified value.
00:11.751	Info	Mouse	Mouse Left Click item 'WindowsApp计算器.NumberPad.Num2Button' at 124;10.
00:13.215	Info	Mouse	Mouse Left Click item 'WindowsApp计算器.StandardOperators.MultiplyButton' at Center.
00:14.052	Info	Mouse	Mouse Left Click item 'WindowsApp计算器.NumberPad.Num7Button' at 0;16.
00:15.578	Info	Mouse	Mouse Left Click item 'WindowsApp计算器.StandardOperators.SomeText' at 5;11.
00:16.696	Info	Validation	Validating AttributeEqual (Text='显示为 14') on item 'WindowsApp计算器.CalculatorResults'.
00:16.801	Success	Validation	Attribute 'Text' of element for item 'Test1Repository.WindowsApp计算器.CalculatorResults' does match the specified value.
00:16.915	Info	Mouse	Mouse Left Click item 'WindowsApp计算器.NumberPad.Num2Button' at 124;10.
00:18.471	Info	Mouse	Mouse Left Click item 'WindowsApp计算器.StandardOperators.DivideButton' at 19;29.
00:19.322	Info	Mouse	Mouse Left Click item 'WindowsApp计算器.NumberPad.Num1Button' at 83;30.
00:20.819	Info	Mouse	Mouse Left Click item 'WindowsApp计算器.StandardOperators.SomeText' at 5;11.
			Validating AttributeEqual (Text='显示为 1') on item 'WindowsApp计算器.CalculatorResults'.
00:22.000	Info	Validation	

00:22.104	Failure	Validation	Attribute 'Text' of element for item 'Test1Repository.WindowsApp计算器.CalculatorResults' does not match the specified value (actual='显示为 2', expected='显示为 1'). 
Module execution was aborted because a validation step has failed. Attribute 'Text' of element for item 'Test1Repository.WindowsApp计算器.CalculatorResults' does not match the specified value (actual='显示为 2', expected='显示为 1').			

之后，使用的修正的代码如下：

```
using System;
using System.Collections.Generic;
using System.Text;
using System.Text.RegularExpressions;
using System.Drawing;
```

```

using Ranorex;
using Ranorex.Core;
using Ranorex.Core.Repository;
using Ranorex.Core.Testing;

namespace Test1
{
    public partial class Recording1
    {
        /// <summary>
        /// This method gets called right after the recording has been started.
        /// It can be used to execute recording specific initialization code.
        /// </summary>
        private void Init()
        {
            // Your recording specific initialization code goes here.

            //打开
            Report.Log(ReportLevel.Info, "Application", "Run application
'C:\\Windows\\System32\\calc.exe' with arguments '' in normal mode.", new
RecordItemIndex(0));
            Host.Local.RunApplication("C:\\Windows\\System32\\calc.exe", "",
"C:\\Windows\\System32", false);
            Delay.Milliseconds(0);

            Report.Log(ReportLevel.Info, "Delay", "Waiting for 1s.", new
RecordItemIndex(1));
            Delay.Duration(1000, false);

            // 清零
            Report.Log(ReportLevel.Info, "Mouse", "Mouse Left Click item 'WindowsApp计算
器.ClearButton' at 86;33.", repo.WindowsApp计算器.ClearButtonInfo, new RecordItemIndex(2));
            repo.WindowsApp计算器.ClearButton.Click("86;33");
            Delay.Milliseconds(200);

            //加法 1+11=12
            Report.Log(ReportLevel.Info, "Mouse", "Mouse Left Click item 'WindowsApp计算
器.NumberPad.Text1' at 2;20.", repo.WindowsApp计算器.NumberPad.Text1Info, new
RecordItemIndex(4));
            repo.WindowsApp计算器.NumberPad.Text1.Click("2;20");
            Delay.Milliseconds(200);

            Report.Log(ReportLevel.Info, "Mouse", "Mouse Left Click item 'WindowsApp计算
器.StandardOperators.SomeText1' at 13;0.", repo.WindowsApp计算
器.StandardOperators.SomeText1Info, new RecordItemIndex(5));
            repo.WindowsApp计算器.StandardOperators.SomeText1.Click("13;0");
            Delay.Milliseconds(200);

            Report.Log(ReportLevel.Info, "Mouse", "Mouse Left Click item 'WindowsApp计算
器.NumberPad.Num1Button' at 83;30.", repo.WindowsApp计算器.NumberPad.Num1ButtonInfo, new
RecordItemIndex(6));
            repo.WindowsApp计算器.NumberPad.Num1Button.Click("83;30");
            Delay.Milliseconds(200);
        }
    }
}

```

```

        Report.Log(ReportLevel.Info, "Mouse", "Mouse Left Click item 'WindowsApp计算器.NumberPad.Num1Button' at 83;30.", repo.WindowsApp计算器.NumberPad.Num1ButtonInfo, new RecordItemIndex(6));
        repo.WindowsApp计算器.NumberPad.Num1Button.Click("83;30");
        Delay.Milliseconds(200);

        Report.Log(ReportLevel.Info, "Mouse", "Mouse Left Click item 'WindowsApp计算器.StandardOperators.SomeText' at 5;11.", repo.WindowsApp计算器.StandardOperators.SomeTextInfo, new RecordItemIndex(7));
        repo.WindowsApp计算器.StandardOperators.SomeText.Click("5;11");
        Delay.Milliseconds(200);

        Report.Log(ReportLevel.Info, "Validation", "Validating AttributeEqual (Text='显示为 12') on item 'WindowsApp计算器.CalculatorResults'.", repo.WindowsApp计算器.CalculatorResultsInfo, new RecordItemIndex(8));
        Validate.AttributeEqual(repo.WindowsApp计算器.CalculatorResultsInfo, "Text", "显示为 12");
        Delay.Milliseconds(100);

        //乘法 2*7=14

        Report.Log(ReportLevel.Info, "Mouse", "Mouse Left Click item 'WindowsApp计算器.NumberPad.Num2Button' at 124;10.", repo.WindowsApp计算器.NumberPad.Num2ButtonInfo, new RecordItemIndex(11));
        repo.WindowsApp计算器.NumberPad.Num2Button.Click("124;10");
        Delay.Milliseconds(200);

        Report.Log(ReportLevel.Info, "Mouse", "Mouse Left Click item 'WindowsApp计算器.StandardOperators.MultiplyButton' at Center.", repo.WindowsApp计算器.StandardOperators.MultiplyButtonInfo, new RecordItemIndex(10));
        repo.WindowsApp计算器.StandardOperators.MultiplyButton.Click();
        Delay.Milliseconds(200);

        Report.Log(ReportLevel.Info, "Mouse", "Mouse Left Click item 'WindowsApp计算器.NumberPad.Num7Button' at 0;16.", repo.WindowsApp计算器.NumberPad.Num7ButtonInfo, new RecordItemIndex(10));
        repo.WindowsApp计算器.NumberPad.Num7Button.Click("0;16");
        Delay.Milliseconds(200);

        Report.Log(ReportLevel.Info, "Mouse", "Mouse Left Click item 'WindowsApp计算器.StandardOperators.SomeText' at 5;11.", repo.WindowsApp计算器.StandardOperators.SomeTextInfo, new RecordItemIndex(7));
        repo.WindowsApp计算器.StandardOperators.SomeText.Click("5;11");
        Delay.Milliseconds(200);

        Report.Log(ReportLevel.Info, "Validation", "Validating AttributeEqual (Text='显示为 14') on item 'WindowsApp计算器.CalculatorResults'.", repo.WindowsApp计算器.CalculatorResultsInfo, new RecordItemIndex(8));
        Validate.AttributeEqual(repo.WindowsApp计算器.CalculatorResultsInfo, "Text", "显示为 14");
        Delay.Milliseconds(100);

        //除法 2/1=2

```

```

        Report.Log(ReportLevel.Info, "Mouse", "Mouse Left Click item 'WindowsApp计算器.NumberPad.Num2Button' at 124;10.", repo.WindowsApp计算器.NumberPad.Num2ButtonInfo, new RecordItemIndex(11));
        repo.WindowsApp计算器.NumberPad.Num2Button.Click("124;10");
        Delay.Milliseconds(200);

        Report.Log(ReportLevel.Info, "Mouse", "Mouse Left Click item 'WindowsApp计算器.StandardOperators.DivideButton' at 19;29.", repo.WindowsApp计算器.StandardOperators.DivideButtonInfo, new RecordItemIndex(11));
        repo.WindowsApp计算器.StandardOperators.DivideButton.Click("19;29");
        Delay.Milliseconds(200);

        Report.Log(ReportLevel.Info, "Mouse", "Mouse Left Click item 'WindowsApp计算器.NumberPad.Num1Button' at 83;30.", repo.WindowsApp计算器.NumberPad.Num1ButtonInfo, new RecordItemIndex(6));
        repo.WindowsApp计算器.NumberPad.Num1Button.Click("83;30");
        Delay.Milliseconds(200);

        Report.Log(ReportLevel.Info, "Mouse", "Mouse Left Click item 'WindowsApp计算器.StandardOperators.SomeText' at 5;11.", repo.WindowsApp计算器.StandardOperators.SomeTextInfo, new RecordItemIndex(7));
        repo.WindowsApp计算器.StandardOperators.SomeText.Click("5;11");
        Delay.Milliseconds(200);

        Report.Log(ReportLevel.Info, "Validation", "Validating AttributeEqual (Text='显示为 2') on item 'WindowsApp计算器.CalculatorResults'.", repo.WindowsApp计算器.CalculatorResultsInfo, new RecordItemIndex(8));
        Validate.AttributeEqual(repo.WindowsApp计算器.CalculatorResultsInfo, "Text", "显示为 2");
        Delay.Milliseconds(100);

        //减法 7-2=5

        Report.Log(ReportLevel.Info, "Mouse", "Mouse Left Click item 'WindowsApp计算器.NumberPad.Num7Button' at 0;16.", repo.WindowsApp计算器.NumberPad.Num7ButtonInfo, new RecordItemIndex(10));
        repo.WindowsApp计算器.NumberPad.Num7Button.Click("0;16");
        Delay.Milliseconds(200);

        Report.Log(ReportLevel.Info, "Mouse", "Mouse Left Click item 'WindowsApp计算器.StandardOperators.MinusButton' at 119;2.", repo.WindowsApp计算器.StandardOperators.MinusButtonInfo, new RecordItemIndex(12));
        repo.WindowsApp计算器.StandardOperators.MinusButton.Click("119;2");
        Delay.Milliseconds(200);

        Report.Log(ReportLevel.Info, "Mouse", "Mouse Left Click item 'WindowsApp计算器.NumberPad.Num2Button' at 124;10.", repo.WindowsApp计算器.NumberPad.Num2ButtonInfo, new RecordItemIndex(11));
        repo.WindowsApp计算器.NumberPad.Num2Button.Click("124;10");
        Delay.Milliseconds(200);

        Report.Log(ReportLevel.Info, "Mouse", "Mouse Left Click item 'WindowsApp计算器.StandardOperators.SomeText' at 5;11.", repo.WindowsApp计算器.StandardOperators.SomeTextInfo, new RecordItemIndex(7));

```

```

        Delay.Milliseconds(200);

        Report.Log(ReportLevel.Info, "Validation", "Validating AttributeEqual (Text='显示为 5') on item 'WindowsApp计算器.CalculatorResults'.", repo.WindowsApp计算器.CalculatorResultsInfo, new RecordItemIndex(8));
        Validate.AttributeEqual(repo.WindowsApp计算器.CalculatorResultsInfo, "Text", "显示为 5");
        Delay.Milliseconds(100);

        //关闭
        Report.Log(ReportLevel.Info, "Mouse", "Mouse Left Click item 'WindowsApp计算器.Close' at 17;26.", repo.WindowsApp计算器.CloseInfo, new RecordItemIndex(9));
        repo.WindowsApp计算器.Close.Click("17;26");
        Delay.Milliseconds(200);
    }

}
}

```

修改完，重新运行功能测试，结果如下：

Recording1

Success

Computer/Endpoint R9000K	Execution time 2024/5/26 23:00:51
Operating system Windows 10 64bit	Screen dimensions 2560x3200
OS Language zh-CN	
Total errors 0	Total warnings 0

Filter: ☒ Info ☒ Success

Time	Level	Category	Message
00:00.947	Info	Application	Run application 'C:\Windows\System32\calc.exe' with arguments '' in normal mode.
00:01.036	Info	Delay	Waiting for 1s.
00:02.051	Info	Mouse	Mouse Left Click item 'WindowsApp计算器.ClearButton' at 86;33.
00:06.911	Info	Mouse	Mouse Left Click item 'WindowsApp计算器.NumberPad.Text1' at 2;20.
00:09.456	Info	Mouse	Mouse Left Click item 'WindowsApp计算器.StandardOperators.SomeText1' at 13;0.
00:11.015	Info	Mouse	Mouse Left Click item 'WindowsApp计算器.NumberPad.Num1Button' at 83;30.
00:13.092	Info	Mouse	Mouse Left Click item 'WindowsApp计算器.NumberPad.Num1Button' at 83;30.
00:15.246	Info	Mouse	Mouse Left Click item 'WindowsApp计算器.StandardOperators.SomeText' at 5;11.
00:16.731	Info	Validation	Validating AttributeEqual (Text='显示为 12') on item 'WindowsApp计算器.CalculatorResults'.
00:16.906	Success	Validation	Attribute 'Text' of element for item 'Test1Repository.WindowsApp计算器.CalculatorResults' does match the specified value.
00:17.011	Info	Mouse	Mouse Left Click item 'WindowsApp计算器.NumberPad.Num2Button' at 124;10.
00:19.135	Info	Mouse	Mouse Left Click item 'WindowsApp计算器.StandardOperators.MultiplyButton' at Center.
00:20.056	Info	Mouse	Mouse Left Click item 'WindowsApp计算器.NumberPad.Num7Button' at 0;16.
00:22.257	Info	Mouse	Mouse Left Click item 'WindowsApp计算器.StandardOperators.SomeText' at 5;11.
00:23.709	Info	Validation	Validating AttributeEqual (Text='显示为 14') on item 'WindowsApp计算器.CalculatorResults'.
00:23.881	Success	Validation	Attribute 'Text' of element for item 'Test1Repository.WindowsApp计算器.CalculatorResults' does match the specified value.
00:23.989	Info	Mouse	Mouse Left Click item 'WindowsApp计算器.NumberPad.Num2Button' at 124;10.
00:26.297	Info	Mouse	Mouse Left Click item 'WindowsApp计算器.StandardOperators.DivideButton' at 19;29.
00:27.216	Info	Mouse	Mouse Left Click item 'WindowsApp计算器.NumberPad.Num1Button' at 83;30.
00:29.360	Info	Mouse	Mouse Left Click item 'WindowsApp计算器.StandardOperators.SomeText' at 5;11.
00:30.866	Info	Validation	Validating AttributeEqual (Text='显示为 2') on item 'WindowsApp计算器.CalculatorResults'.
00:31.041	Success	Validation	Attribute 'Text' of element for item 'Test1Repository.WindowsApp计算器.CalculatorResults' does match the specified value.
00:31.148	Info	Mouse	Mouse Left Click item 'WindowsApp计算器.NumberPad.Num7Button' at 0;16.
00:33.365	Info	Mouse	Mouse Left Click item 'WindowsApp计算器.StandardOperators.MinusButton' at 119;2.
00:34.288	Info	Mouse	Mouse Left Click item 'WindowsApp计算器.NumberPad.Num2Button' at 124;10.
00:36.424	Info	Mouse	Mouse Left Click item 'WindowsApp计算器.StandardOperators.SomeText' at 5;11.

这样发现就不会出现问题了，符合预期的结果。